

Montaż przycisku zdalnego startu seansu



1. Wstęp



Niniejsza instrukcja jest wersją skróconą instrukcji sterownika sauny. Przed przystąpieniem do montażu należy bezwzględnie zapoznać się z zasadami bezpieczeństwa opisanymi i wyszczególnionymi w instrukcji sterownika sauny serii ZXX, CXX/CXXmini. Instrukcje można pobrać ze strony <https://ffes.pl/do-pobrania/>

2. Skład zestawu

Pozycja	Nazwa	Ilość	Zdjęcie poglądowe
1	Przycisk w ramce	1	

3. Narzędzia potrzebne do montażu


- Wkrętarka
- Wiertło Ø20mm
- Gratownik do otworów
- Śrubokręt płaski



Przed przystąpieniem do prac montażowych należy wyłączyć zasilanie urządzenia, w którym będą dokonywane zmiany!

4. Podłączenie przycisku do płyty głównej – lokalizacja wyjść na płycie głównej modułu mocy sterownika

- Przycisk – podłączenie




1 – Zasilanie podświetlenia przycisku 12V (-)

2 – Zasilanie podświetlenia przycisku 12V (+)

3 – Podłączenie pod I grupę (I2) / II grupę (I3)

4 – Podłączenie pod I grupę (V-) / II grupę (V-)

- Płyta główna - podłączenie



1

2

3 - I grupa

4 - I grupa

3 - II grupa

4 - II grupa

5. Aktywacja przycisku zdalnego startu seansu

Aktywacji dokonać wg instrukcji obsługi sterownika sauny w zależności od serii ZXX / CXX / CXXmini - szczegółowe informacje zostały opisane w rozdziale 8.3.2

Installation of a remote start button for the session




1. Introduction



This manual is a shortened version of the sauna controller manual. Before starting the installation, it is essential to read the safety rules described and detailed in the instructions for the ZXX, CXX/CXXmini series sauna controller. Instructions can be downloaded from <https://ffes.pl/en/download/>

2. Set composition

Position	Name	Quantity	Photo
1	Button in frame	1	

3. Tools needed for assembly


- Screwdriver
- Drill Ø20mm
- Hole deburrer
- Flat screwdriver




Before starting assembly work, turn off the power supply to the device in which changes will be made!

4. Connecting the button to the motherboard - location of the outputs on the motherboard of the controller power module

- Button – connection



- Motherboard - connection



5. Activation of the remote start button

Activate according to the sauna controller user manual depending on the ZXX / CXX / CXXmini series - detailed information is described in chapter 8.3.2